



WWW.INSTANTAWNINGS.CO.UK


Setup Instructions



Place the awning frame on the ground, and open out to arms width with two people on opposite sides of the frame.



Place the canopy over the partially expanded frame and attach the canopy at each corner using the Velcro pads.



Each person now needs to place one hand at the top and one hand at the bottom of the 'cross truss' section in the middle of the frame, as shown above. By pushing the top and bottom towards each other, the frame will expand outwards with ease.



Now both move to the same end of the awning, and place your foot on the corner foot pad. Simultaneously lift the outer leg upwards until it locks in to place at the first height setting. Repeat the process with all other legs until you reach the desired height.



Fold the corners of the canopy upwards slightly to expose the top of the frame leg. This will enable you to lock the corner joint bracket into place at the top.



Once you have locked the corner joint in place, fold the canopy back down. Your Instant Awning is now ready to use!



Side Wall Setup Instructions

Preparation

1. Remove the full side wall set from the brown cardboard packaging box.
2. The side wall set will arrive zipped together as one complete length. It is easiest to unzip the middle zip and split the walls into two sections.

Attaching Side Walls

3. The first step is to roll the canopy back up at each corner so that most of the velcro pad at the top of the frame leg is exposed.
4. Now fix the first side wall panel onto the velcro pad at the top of each corner leg, where the canopy was attached before you rolled it upwards.
5. For extra security, tie the side walls on to the frame legs using the white strings.
6. Now roll the canopy back down over the top of the side wall – this will hold the side wall firmly in place.
7. Repeat this process with all other side walls if required. Where two walls meet at the corner, use the zip to connect walls together.

To summarise - when using a canopy only, the canopy attaches directly to the Instant Awnings frame using the velcro pads. When using a side wall set, the side walls attach directly to the velcro frame pads, and the canopy folds over the top also attaching with velcro pads. Securing the side walls in this way will make them as secure as possible and completely water tight!

If you need any further help, please do not hesitate to contact us on 01743 457 833